

USER'S MANUAL



Alecto[®]

ADI-250

1.	INTRODUCTION.....	3
2.	INTENDED USE	3
3.	PACKAGING CONTENTS.....	3
4.	INSTALLATION	4
4.1	Charger	4
4.2	Indoor unit	4
4.3	Outdoor unit	5
	Batteries	5
	Power adaptor	5
	Mounting.....	6
5.	OVERVIEW.....	7
5.1	Indoor unit	7
5.2	Outdoor unit	7
6.	OPERATION	8
6.1	To switch on/off	8
6.2	When the doorbell rings	8
6.3	Monitor (looking outside yourself)	9
7.	SETUP	10
7.1	Volume	10
7.2	Brightness	10
7.3	Time and date	11
7.4	Key tone	11
7.5	Automatic snapshot	11
7.6	To view photos	12
7.7	Reset to factory settings	12
8.	EXPANDING WITH MULTIPLE OUTDOOR UNITS	13
8.1	Introduction	13
8.2	To register additional outdoor units	13
8.3	To de-register	14
9.	INCREASING THE RANGE USING THE EXTERNAL ANTENNA	14
10.	PHOTOS.....	15
10.1	Introduction	15
10.2	To view and delete	15
11.	DOOR OPENER	15
11.1	Introduction	15
11.2	Operating the door lock	16
11.3	Door lock connection	16
11.4	Door lock switch duration setup	17
12.	SYSTEM ERROR	17
13.	TECHNICAL SPECIFICATIONS	17
13.1	Indoor-unit.....	17
13.2	Outdoor-unit	18


1. INTRODUCTION

The ADI-250 is a wireless video door telephone system. It allows you to see who's at the door and to ask what the purpose of the visit is before you open the door. Additionally, a photo is taken of each visitor ringing your doorbell, including the date and time, which is saved in the memory of the indoor post. The indoor post has a memory capacity for 50 of these photos.

2. INTENDED USE

The Alecto ADI-250 allows you to wirelessly see who's at the door and to communicate with this person. The Alecto ADI-250 is only suitable for household use and can in no way prevent undesired visitors.


3. PACKAGING CONTENTS




outdoor unit with built-in camera and microphone / speaker, suspension bracket, optionally with battery compartment (extra large suspension bracket)



indoor unit with built-in display and microphone / speaker and rechargeable battery pack and belt clip



charger with adaptor




screwdriver with screws for installation and mounting

4. INSTALLATION


4.1 Charger:

1. Insert the small plug of the adaptor cable into the bottom of the adaptor and plug the adaptor into a 230V wall socket.
 2. You may choose to place the charger into a table or to use the 2 screws for wall-mounting.
- The adaptor for the charger is included.




4.2 Indoor unit:

1. Slide the battery cover at the rear of the indoor unit down and off the indoor unit.
2. Install the supplied battery pack in the indoor unit, connecting the plug to the battery input.
3. Slide the battery cover back onto the indoor unit.
4. You may also place the belt clip.
5. Place the indoor unit into the charger and leave it there for 10-15 hours to properly charge the battery pack.



The charge indicator will remain lit while charging (attention: this indicator will NOT switch off when the battery pack is charged).





4.3 Outdoor unit:

You may choose to have the outdoor unit run on batteries or power it via a power adaptor. When powered by batteries, the monitor function will be unavailable. Batteries or a power adaptor for the outdoor unit are NOT included. You may also choose to use the standard doorbell transformer; the current doorbell and bell pusher will then be excluded.


Batteries: (size AA, penlite LR-6, 1.5V, 4x, excluded)

1. Remove the protective cover by flipping off the cover using a screwdriver underneath the clip.
2. Remove the battery cover by unscrewing the 4 small screws.
3. Install the batteries, paying attention to the + and -. Preferably, use Alkaline batteries.
4. Replace the battery cover onto the outdoor unit, fasten it with the 4 small screws and replace the protective cover.
5. Click the battery compartment into the bottom of the outdoor unit.




Power adaptor: (8~12V AC or DC, 1000mA, excluded)

1. Remove the seal cover by unscrewing the 4 small screws.
2. Connect the 8-12V adaptor according to the illustration below.
3. Fasten the seal cover back onto the outdoor unit.




First, strip the insulation approximately 1cm.
You may ignore the (+) and (-) connection.
Push in the wire and fix it.




You may hide the connection for the battery compartment with the supplied rubber panel with bonding strip. Remove the protective layer of the rubber panel and stick it onto the bottom covering the connections.

Mounting:

1. Determine the installation height for the outdoor unit.
2. Hold the suspension bracket against the wall at the desired height and draw the drill holes.
3. Drill the holes, insert the plugs and mount the suspension bracket. You can suspend the bracket exactly straight using the built-in spirit level. When using an external power source, lead the wires through the hole in the rear of the suspension bracket and connect them to the connection strip.
4. Now first slide the top of the outdoor unit into the suspension bracket and then push the bottom into the bracket, according to the illustration below.
5. Now fasten the outdoor unit into the bracket using the supplied screw.




If the camera must be aimed at an angle to the left or right, first mount the wall bracket at an angle to the wall and then place the straight wall bracket onto it.



5. OVERVIEW

5.1 Indoor unit:

1. Display
2. Left soft-button
3. Talk button, to answer calls
4. Charge LED indication
5. Manual snapshot, camera selection button
6. Direction buttons
7. Built-in microphone
8. Power button, Stop button, to end calls
9. Right soft-button, to show images, to unlock
10. Switch for clicking the external antenna outward for improved range
11. External antenna
12. Built-in speaker
13. Battery compartment
14. Charger
15. Adaptor cable input



5.2 Outdoor unit:

16. Built-in speaker
17. Night light
18. Built-in camera
19. Photo cell
20. Bell pusher with built-in lighting
21. Built-in microphone
22. Separate battery compartment


6. OPERATION

6.1 To switch on/off:

Outdoor unit:

As soon as the batteries are installed or the adaptor is connected, the outdoor unit will be enabled. The outdoor unit cannot be switched off.

Indoor unit:

Press and hold the  button for 2 seconds to switch on the indoor unit.



Press and hold the  button again for 4 seconds to switch off the indoor unit.



Attention: the indoor unit is NOT switched off automatically when placed into the charger.


6.2 When the doorbell rings:





Upon pressing the push button, the push button will illuminate. A “ding dong” sound will be emitted and the face of the visitor will be shown on the display of the indoor unit.



- when the surrounding light is inadequate, the object lighting of the outdoor unit is enabled
- a photo of the visitor is taken automatically and is stored in the memory of the indoor unit (see also chapter 9)
 - when you do nothing, the call is ended automatically after ± 20 seconds
 - if you want to ignore this visit, press the  button; the image of the visitor will disappear from the display
 - if you'd like to talk to your visitor, you may press the  button to accept the call

After accepting the call:

- You may talk to your visitor through the built-in microphone and speaker in the indoor unit and in the outdoor unit; please keep in mind NOT to hold the indoor unit against your ear like a regular telephone receiver. Leave the indoor unit in the charger while talking to your visitor or keep the indoor unit in your hand at approx. 30cm from your mouth and speak at a normal voice volume level.



- the volume of the speaker of the indoor unit may be adjusted using the  and  buttons (the volume of the speaker of the outdoor unit is fixed and cannot be changed).
- use the  and  buttons to set the screen brightness.






- a photo was already taken upon ringing the doorbell, but you may choose to take another picture of your visitor during your conversation by pressing the  button.
- press the  button to disconnect the call (or wait for 2 minutes until the call is disconnected automatically)

When multiple outdoor units are registered:





When multiple outdoor units are registered and somebody presses the doorbell, the camera number X# in the upper part of the screen will indicate at which outdoor unit your visitor is calling.

6.3 Monitor: (looking outside yourself)

Also when there's nobody pressing the doorbell, you may still enable the camera and take a picture.


- briefly press the  button to switch on the indoor unit from its sleep mode
- press and hold the  soft-button for 1 second to switch on the monitor function; the display will be enabled to show the area in front of the camera
- you may listen via the speaker (talking back is only possible after pressing the  button)
- press the  button to take a picture
- press the  button to disconnect or wait for 5 minutes until the connection is disconnected automatically

When multiple outdoor units are registered:

When multiple outdoor units are registered and you press and hold the  button for 1 second, you must first use the  and  buttons to select the desired outdoor unit and then press the  button to confirm.




Attention: if the outdoor unit is powered by batteries, the monitor function is NOT available.



7. SETUP

Via the menu function of the indoor unit, you may manage the various settings of the video door phone.



Battery capacity indication



Talk-back indication



Indication while zooming



Power indication, the intercom is connected to fixed power



Call signal disconnected












Active camera



RF signal strength










7.1 Volume:

Except for when in use, you may adjust the volume in the menu:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Volume function
4. press the  Select soft-button
5. use the  and  buttons to set the volume
6. press 2x the  BACK soft-button to save your settings and to leave the menu












7.2 Brightness:

Except for when in use, you may adjust the Brightness in the menu:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Brightness function
4. press the  Select soft-button
5. use the  and  buttons to set the Brightness
6. press 2x the  BACK soft-button to save your settings and to leave the menu











7.3 Time and date:

The photo of the visitor also shows the time and date. You may set the time and date here:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Date & Time function
4. press the  Select soft-button
5. press the  and  buttons to switch between hours, minutes, day and date and use the  and  buttons to change the settings
6. press 2x the  BACK soft-button to save your settings and to leave the menu











7.4 Key tone:

Each time you press a button, a key tone will be emitted. You may enable or disable this key tone:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Key tone function
4. press the  Select soft-button
5. use the  and  buttons to select whether you want to switch the key tone On or Off
6. press the  Select soft-button to save your setting and press the  BACK button to leave the menu


7.5 Automatic snapshot:

Of each visitor pressing the doorbell a photo is taken automatically. You may disable or enable this function or set it to 1 photo/press, 2 photos/press or 3 photos/press:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Auto. snap set function.
4. press the  Select soft-button
5. use the  and  buttons to set the automatic snapshot to On or Off
6. press the  Select soft-button to save your setting and press the  BACK button to leave the menu


7.6 To view photos:

Of each visitor pressing the doorbell a photo is taken automatically (the automatic snapshot function must be enabled). You may view these photos as follows:




1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit

2. press the  REPLAY button

OR

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit

2. press the  MENU soft-button


3. use the  and  buttons to select the  Snap show function.

4. press the  Select soft-button

Now the last photo taken will appear in the display.


The red letter in the upper part of the screen indicates which camera has taken the photo.

The green digits represent the photo number.




Press the  Del button to delete a photo.




Press the  BACK button to leave the photo viewer.

7.7 Reset to factory settings:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit

2. press the  MENU soft-button

3. use the  and  buttons to select the  Default Set function.

4. press the  Select soft-button and use the  and  buttons to choose whether to perform a factory reset (Yes) or not (No)

Factory settings:

volume: level 5

brightness: level 5

key tone: on

automatic 1 snapshot: on

photo memory: empty

8. EXPANDING WITH MULTIPLE OUTDOOR UNITS

8.1 Introduction:

Up to a maximum of 4 outdoor units may be connected to a single indoor unit. In this way you can guard multiple entrances to your company or home (main entrance, personnel entrance, warehouse, garden gate, and garage).







Additional outdoor units are available via the Alecto service department on telephone number 073 6411 355 (Netherlands) or 03 238 5666 (Belgium) or via the internet www.alecto.nl

8.2 To register additional outdoor units:





Preparation for registration:

1. Install the batteries into the indoor unit and charge them.
2. Install the batteries into the outdoor unit or connect the adaptor to the unit
3. Keep both the indoor unit and outdoor unit handy
4. Keep a small screwdriver or paperclip handy

To register:


1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  MENU soft-button
3. use the  and  buttons to select the  Register function
4. press **2x** the  SELECT soft-button; in the lower part of the display 'Searching...' will appear.
5. press 1x the bell pusher of the outdoor unit
6. now press and hold the register button at the rear of the outdoor unit until the camera lighting starts flashing after several seconds
7. the indoor unit and outdoor unit are now searching for each

other; the registration is successful as soon as the indoor unit shows the image of the outdoor unit; the number of the outdoor unit is indicated in the middle of the display at the top






Maximum 4 outdoor units.


The indoor unit is suitable for registering 4 outdoor units. As soon as you try to register a fifth outdoor unit, the warning “Register Full” will appear.



8.3 To de-register:

You can only de-register ALL outdoor units at once. After doing so you may choose to register a certain outdoor unit again.


1. With the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. Now simultaneously press the  button and the right  button and press and hold these buttons for 5 seconds.
3. After 5 seconds the message ‘Registration Cleared’ will appear and all outdoor units are now de-registered.



9. INCREASING THE RANGE USING THE EXTERNAL ANTENNA

The indoor unit is provided with an external antenna. The antenna sits on top of the indoor unit.

1. Push the silver button to the right.
2. The external antenna will pop out.
3. Rotate the antenna until it's standing upright to increase the reception sensitivity.











10. PHOTOS

10.1 Introduction:

- Of each person pressing the doorbell a photo is taken automatically.
- This photo is saved in the internal memory of the indoor unit, including the time and date of that picture.
- You may also take photos yourself in the monitor mode.
- The photos are saved in the internal memory of the indoor unit and CANNOT be copied or moved elsewhere.
- The indoor unit has a memory capacity for 50 photos.
- Via the menu function of the indoor unit you may disable the automatic snapshot function for visitors.
- The indoor unit has a memory capacity for 50 photos. When the memory is full, each new photo will overwrite the oldest photo in the memory. You CANNOT export the photos


10.2 To view and delete:

1. with the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. press the  Replay soft-button; the most recent photo will be shown
3. use the  and  buttons to scroll the photo directory
4. in the bottom of the screen the time and date of the snapshot are shown
5. in the upper middle part of the screen the order number of the photo is shown
6. press the left  DEL soft-button to delete the current photo, press the right  YES button to confirm or press the left  NO soft-button to cancel

In addition to using the  Replay soft-button, you may also view photos via the menu by selecting the 'Snap Show' option in the setup menu.



11. DOOR OPENER

11.1 Introduction:

The indoor post is provided with a control function to open an automatic electric door lock. This function is only available when the talk-back function () is activated and the outdoor unit is connected to an external adaptor. The outdoor unit can control both NC (normally closed) and NO (normally opened) door locks.


11.2 Operating the door lock:

You may activate the door lock as follows.

1. Upon pressing the push button, the push button will illuminate. A 'ding dong' bell signal is emitted and the face of your visitor appears in the display of the indoor unit.
2. To talk to your visitor, press the  button to accept the call.
3. Press the  button to activate the door lock.
4. Your visitor can now open the door and enter.









11.3 Door lock connection:


The door lock may be connected according to the illustration below.



11.4 Door lock switch duration setup:

You may set a time for how long the door lock can be activated.

1. With the indoor unit on stand-by, first briefly press the  button to wake up the indoor unit
2. Now simultaneously press the  button and the right  button and press and hold these buttons for 5 seconds. “Unlock time” will appear in the display.
3. Use the  and  buttons to select the correct outdoor post with door lock (1~4)
4. Press the  or  button to set the switch duration (1~25 sec.)
5. Now press the  Back soft-button; “OK” will appear in the display as a confirmation.
6. The screen turns off automatically after 5 seconds.



12. SYSTEM ERROR

If you think that an error has occurred in the system, please remove the batteries from the indoor unit and outdoor unit. Now wait several minutes and replace the batteries. If this does not resolve the problem, please contact the Alecto service department at telephone number 073 6411 355 (Netherlands) or 03 238 5666 (Belgium) or via the internet www.alecto.nl

13. TECHNICAL SPECIFICATIONS

13.1 Indoor-unit

Receiving Frequency Range:	2.400GHz ~ 2.4835GHz
Monitor:	3.5" Color LCD
Data Rate:	2.0Mbps
Receiving Sensitivity:	-90dBm
Demodulation Type:	GFSK
Resolution:	320x240(RGB)
Transmitting Power:	19dBm (TYP)
Power Requirement:	Ni-MH3.6V, 800mAh
Power Consumption:	400mA Max
Operating Temperature:	-10°C ~ 40°C
Operating Humidity:	0% ~ 85%RH
Weight:	188g
Size receiver:	85x115x27mm (WxHxD)
charger:	93x55x75mm (WxHxD)
No. of outdoor stations:	Max.4

13.2 Outdoor-unit

Transmit Frequency:	Range 2.400GHz ~ 2.4835GHz
Data Rate:	2.0Mbps
Transmitting Power:	19dBm (TYP)
Modulation Type:	GFSK
Transmitting Distance:	Outdoor: 200m, Indoor: 50m
Image Sensor Type:	1/4" Color CMOS Image Sensor
Effective Pixels:	H:320 V:240
Image Processing:	Motion JPEG
Image Resolution / Frame Rate:	H:320 V:240 / 25fps
White Balance:	Auto
Lens:	2.1mm / F2.6
Viewing Angle (Diagonal):	135°
Minimum Illumination:	1 LUX (without LED illumination)
LED:	6 LEDs
Power Requirement:	8~12V AC or DC +/- 5% 4 LR6(AA), 1.5V alkaline batteries
Power Consumption:	500mA Max (cells) 400mA Max (8~12V AC or DC)
<i>Door contact:</i>	
<i>Contact rating (Res. load):</i>	<i>0.3A 60VDC / 0.5A 125VAC / 1A 30VDC</i>
<i>Max. switch voltage:</i>	<i>125VAC / 60VDC</i>
<i>Max. switching current:</i>	<i>2A</i>
<i>Max. switching power:</i>	<i>62.5VA / 30W</i>
Operating Temperature:	-30°C ~ 40°C
Operating Humidity:	0% ~ 85%RH
Weight:	109g excl. 251 incl. batteries
Size:	50x125x35mm (WxHxD) excl. batteries 50x200x35mm (WxHxD) incl. batteries



Service



Help



WWW.ALECTO.NL
SERVICE@ALECTO.NL

NL 073 6411 355

(Lokaal tarief)



BE 03 238 5666

(Lokaal tarief)

(Tarif local)

DE 0180 503 0085

Lokale Festnetzkosten



Hesdo, Australiëlaan 1
5232 BB, 's-Hertogenbosch
The Netherlands